


REMOTE CONTROL INSTRUCTION MANUAL - AIRTIES



For more information, please call 101
or visit www.etisalat.ae/elife



Key	Basic Functions	
1	Power	Switch on and off
2	Radio	Radio
3	1-9#	Channel navigation
4	Menu	Menu
5	EPG	Display search/filter menu
6	Arrow Up	Move selection up
	Arrow Down	Move selection down
	Arrow Left	Move selection left
	Arrow Right	Move selection right
	OK	OK/Enter
7	Back	Exit or go back
8	Information	Launch information/ extended information
9	Mute	Mute the audio
10	Volume Up/Down	Increase and decrease volume
11	Channel Up/down	Surf channels
12	Play	Playback
	Stop	To stop playback. Return to live TV
	Rew	To rewind/Page down (in case PVR functions are being used)
	FFW	To fast forward/Page up
13	Pause	To pause TV
14	Record	To start recording

Additional functions

In Live TV, with info bar on display or within channel list, press up key to show the program details and PIP of the next channel.

In Live TV, with info bar on display or within channel list, press down key to show the program details and PIP of the previous channel.

In Live TV, with info bar on display, press left key to show the previous program details. With no info bar on display, press left key to zap to the last channel watched.

In Live TV, with info bar on display, press right key to show the next program details. With no info bar on display, press right key to display the channel list.

To delete any input into the text box

Return to Live TV (in case PVR functions are being used)